



No Right Angles

No. 1451-101 LAF CHAIR

W 50 D 38 H 27½ in.
Seat depth 23 in.
Seat height 18 in.
Arm height 27½ in.
Arm width 3 in.

No. 1451-210 CURVED CORNER

W 64 D 38 H 27½ in.
Seat depth 23 in.
Seat height 18 in.

Height to top of back cushion is 36 inches approximately.

No. 1451-436 RIGHT CHAISE

W 72 D 38 H 27½ in.
Seat depth 23 in.
Seat height 18 in.



No Right Angles 1451 - Series

Scale 1/4" = 1'0"
All upholstery sizes are approximate



No. 1451-435 LEFT CHAISE

W 72 D 38 H 27½ in.
Seat depth 23 in.
Seat height 18 in.

No. 1450-102 RAF CHAIR

W 50 D 38 H 27½ in.
Seat depth 23 in.
Seat height 18 in.
Arm height 27½ in.
Arm width 3 in.



No. 1451-513 STUDIO SOFA

W 86 D 46 H 27½ in.
Seat depth 23 in.
Seat height 18 in.
Arm height 27½ in.
Arm width 3 in.

Height to top of back cushion is
36 inches approximately.



No. 1451-313 SOFA

W 102 D 48 H 27½ in.
Seat depth 23 in.
Seat height 18 in.
Arm height 27½ in.
Arm width 3 in.

Height to top of back cushion is
36 inches approximately.